

Цепь	Конт.
NC	1
IOREF	2
RESET	3
+3,3B	4
+5B	5
GND	6
GND	7
VIN	8

Конт.	Цепь
1	IO8
2	IO9
3	IO10/SS
4	IO11/MOSI
5	IO12/MISO
6	IO13/SCK
7	GND
8	AREF
9	SDA
10	SCL

Цепь	Конт.
AD0	1
AD1	2
AD2	3
AD3	4
AD4	5
AD5	6

Конт.	Цепь
1	IO0/RxD
2	IO1/TxD
3	IO2/INT0
4	IO3/INT1
5	IO4/T0
6	IO5/T1
7	IO6/AIN0
8	IO7/AIN1

